



Replacing a Single Server or Cluster for Cisco Unified Communications Manager Release 8.6(1)

This document describes how to replace a single server or an entire cluster for Cisco Unified Communications Manager Release 8.6(1). Replacement means that you replace the server hardware while preserving the server configuration. The replacement server operates identically to the old server.



Caution

Because this process is designed to work as a server replacement, you need to do it in the live environment. Cisco does not recommend doing this process on a “dead net” because a duplication of the entire network environment is required, which is highly risky.

These sections describe the major tasks that are required to replace a server or cluster:

- [Server or Cluster Replacement Preparation Checklist, page 2](#)
- [Replacing a Single Server or Cluster, page 12](#)
- [Post-Replacement Checklist, page 29](#)
- [Upgrading Server Hardware When Upgrading to Cisco Unified Communications Manager Release 8.6\(1\), page 32](#)

Related Documentation

For additional installation-related information, refer to the following documents:

- *Upgrading Cisco Unified Communications Manager*
http://www.cisco.com/en/US/products/sw/voicesw/ps556/prod_installation_guides_list.html
- *Installing Cisco Unified Communications Manager*
http://www.cisco.com/en/US/products/sw/voicesw/ps556/prod_installation_guides_list.html
- *Cisco Unified Communications Operating System Administration Guide*
http://preview.cisco.com/en/US/products/sw/voicesw/ps556/prod_maintenance_guides_list.html

For further information about related Cisco IP telephony applications and products, refer to the *Cisco Unified Communications Manager Documentation Guide*:



Americas Headquarters:
Cisco Systems, Inc., 170 West Tasman Drive, San Jose, CA 95134-1706 USA

http://cisco.com/en/US/products/sw/voicesw/ps556/products_documentation_roadmaps_list.html.

Table 1 lists URLs for software and additional documentation.

Table 1 Quick Reference for URLs

Related Information and Software	URL
Cisco MCS data sheets	http://www.cisco.com/en/US/products/hw/voiceapp/ps378/index.html
Software-only servers (IBM, HP, Compaq, Aquarius)	http://www.cisco.com/en/US/products/hw/voiceapp/ps378/prod_brochure_list.html
Cisco Unified Communications Manager service releases	http://www.cisco.com/kobayashi/sw-center/sw-voice.shtml

Server or Cluster Replacement Preparation Checklist

This section describes that tasks that you should perform before you begin the server or cluster replacement.

Pre-Replacement Task	Important Notes
Step 1 Verify the integrity of the new server hardware (such as hard drives and memory) by running any manufacturer-provided utilities.	
Step 2 Make sure that the new servers are listed as supported hardware and sized appropriately to support the load of cluster.	Refer to the following documentation for information about the capacity of server models: <ul style="list-style-type: none"> Release notes for your product release http://www.cisco.com/en/US/products/hw/voiceapp/ps378/prod_brochure_list.html Make sure to account for any growth that has occurred since initial system configuration.
Step 3 Verify that links between servers meet the delay requirements and that you have enough bandwidth to support database replication.	For more information, refer to <i>Cisco Unified Communications SRND Based on Cisco Unified Communications Manager 7.x</i> .
Step 4 Record all system passwords and account IDs.	See the “Recording Account Names and Passwords” section on page 5. You must enter identical passwords when configuring the replacement server. You cannot retrieve these passwords from the server.
Step 5 Make sure that you have a copy of all custom ring files, phone backgrounds, and music on hold sources.	Consider this actions as precautionary because the restore is designed to restore these items.
Step 6 Obtain and store COP files for any locales that are installed on the server.	You need to reinstall locales after doing the replacement.
Step 7 Do not change computer names or IP addresses, or add more nodes to the cluster.	

Pre-Replacement Task	Important Notes
Step 8 Verify the integrity of your software downloads and DVDs.	Perform the following tasks: <ul style="list-style-type: none"> • Check the MD5 checksum of downloaded software against the published value to verify that it downloaded properly. • Verify that the DVD is readable by a DVD drive.
Step 9 If your firewall is not in the routing path, disable the firewall between nodes, if possible. Also, increase the firewall timeout settings until after you complete the installation.	It is not always sufficient to temporarily allow network traffic in and out of the nodes (for example, setting the firewall rule for these nodes to <code>IP any/any</code>). The firewall might still close necessary network sessions between nodes due to timeouts.
Step 10 Perform any system tests that you intend to perform after the replacement before the replacement also, to verify that the tests pass before you do the replacement.	Document these tests, so you can perform them identically after doing the replacement.
Step 11 If you use DNS, verify that all servers that are to be replaced are configured in DNS properly. All nodes in the cluster must either use DNS or not use it.	See the “Verifying DNS Registration” section on page 8 .
Step 12 Do not run Network Address Translation (NAT) or Port Address Translation (PAT) between Cisco Unified Communications Manager nodes.	
Step 13 Record all the registration information by using the Cisco Unified Communications Manager Real Time Monitoring Tool (RTMT).	See the “Determining Registration Counts by Using RTMT” section on page 8 . You cannot perform this task if your old server is not working.
Step 14 Record all the critical services and their activation status by using the Cisco Unified Communications Manager Real Time Monitoring Tool (RTMT).	See the “Recording Critical Service Status” section on page 9 . You cannot perform this task if your old server is not working.
Step 15 Using the Syslog viewer in the Cisco Unified Communications Manager Real Time Monitoring Tool (RTMT), locate any events that have a severity of Error or higher.	Perform this task to ensure that no system-affecting errors exist on your system. See the “Locating System Errors by Using Syslog Viewer” section on page 9 . You cannot perform this task if your old server is not working.
Step 16 Record the details of all Trace and Log Central jobs.	See the “Recording Trace and Log Central Job Details” section on page 10 . You cannot perform this task if your old server is not working.
Step 17 Record CDR Management configuration and destinations, if applicable.	See the “Accessing CDR Management Configuration” section on page 10 . You cannot perform this task if your old server is not working.

Pre-Replacement Task	Important Notes
<p>Step 18 From Cisco Unified Communications Manager Administration, determine the number of specific items that are configured on the server.</p>	<p>See the “Determining System Configuration Counts” section on page 11.</p> <p>You cannot perform this task if your old server is not working.</p>
<p>Step 19 From Cisco Unified Communications Manager Administration, record all the phone loads and device types that display on the Firmware Load Information window.</p>	<p>See the “Firmware Information” section on page 11.</p> <p>If you have custom device types that do not ship with Cisco Unified Communications Manager, make sure that you have the appropriate COP files. You need to reinstall the devices types after performing the replacement.</p> <p>You cannot perform this task if your old server is not working.</p>
<p>Step 20 Record all network configuration settings and other configuration settings that are described in the sections that are referenced in the Important Notes column for each server to be replaced.</p>	<p>See the following sections:</p> <ul style="list-style-type: none"> • “Recording Network Configuration Settings” section on page 5. • “Recording SMTP Settings” section on page 7 • “Recording the Hostname and Timezone Settings” section on page 7 <p>You cannot perform this task if your old server is not working.</p>
<p>Step 21 Compare the system version on each node in your cluster by using Cisco Unified Communications Manager Administration.</p> <p>Verify that you have DVDs with that version.</p>	<p>See the “Obtaining System Version Information” section on page 12.</p> <p>If you have a service release, you need media for the base release and the service release.</p>
<p>Step 22 If your cluster is running in secure mode, make sure that you have USB eToken devices and CTL Client plug-in utility installed on a computer that is running the Windows operating system.</p>	<p>For information about performing these tasks and about Cisco Unified Communications Manager security, refer to the “Installing the CTL Client” procedures in the <i>Cisco Unified Communications Manager Security Guide</i>.</p>
<p>Step 23 Perform a DRS backup on the publisher server to a remote SFTP server and verify that the backup succeeds.</p> <p>Record the DRS backup location and schedule information, if applicable.</p>	<p>To verify that your SFTP is working, use an SFTP client on a computer on the same subnet as the servers that are being restored and download the backup to that computer.</p> <p>Ensure that all cluster nodes that you will replace or reinstall are online and registered as a node. DRS backs up only registered and online nodes.</p> <p>You cannot perform this task if your old server is not working.</p> <p>See the “Creating a Backup File” section on page 16.</p>

Gathering System Configuration Information to Replace or Reinstall a Server

Before replacing or reinstalling a server, you must have the information that is described in this section. The information that is provided must match before and after the restore or reinstall. In the case of a server replacement, this information must match on both the original server and its replacement.

Gather this information for each Cisco Unified Communications Manager server that you are replacing or reinstalling in the cluster. You may not need to obtain all the information; gather only the information that is pertinent to your system and network configuration.

Recording Account Names and Passwords

Record all system passwords and account IDs, including those described in [Table 2](#). You cannot retrieve these passwords from the server.



Caution

You must enter identical passwords and account IDs when you configure the replacement server.

If you replace a server that was previously upgraded from an older product release, your passwords might get denied by the Cisco Unified Communications Manager installation program. This happens because the password validation rules might get stronger in the new product release, but passwords do not get re validated during an upgrade. But when you perform a fresh installation on the server that you are replacing, the new, stronger password validation occurs.

If this happens, choose new passwords that the installation program will accept. For more information about passwords, see the document *Installing Cisco Unified Communications Manager*.

Table 2 Password and Accounts Configuration Data

Field	Description
Administrator ID: _____	The user ID that you use for secure shell access to the CLI, for logging into Cisco Unified Communications Manager Administration, and for logging into the Disaster Recovery System.
Administrator Password _____	The password that you use to log into the Administrator ID account.
Application User Name _____	The default Application User name for applications that are installed on the system, including Cisco Unified Communications Manager and Cisco Unified Serviceability. In 5.x releases, the Application User Name is set automatically during installation to CCMAAdministrator. In 6.x releases, you choose the Application User Name during installation.
Application User Password _____	The password that is used as the default password for applications that are installed on the system, including Cisco Unified Communications Manager Administration and Cisco Unified Serviceability.
Security Password: _____	The security password that Cisco Unified Communications Manager servers in the cluster use to communicate with one another. You must enter the same password for all nodes in the cluster.

Recording Network Configuration Settings

Follow this procedure to record network configuration settings.



Caution

You must enter identical network settings when you configure the replacement server. Do not attempt to change network settings on the replacement server. The only exceptions are the NIC speed and duplex settings, which you should configure as described in this section.

Procedure

- Step 1** In Cisco Unified Communications Operating System Administration, navigate to **Show > Network**.
- Step 2** Record all network configuration settings, including those described in [Table 3](#).
- Step 3** Record the NIC speed and duplex settings of the switch port to which you will connect the new server. You should configure the same NIC settings on the server and on the switch port. For GigE (1000/FULL), you should set both NIC and switch port settings to Auto/Auto; do not set hard values. If you are using Network Fault Tolerance, the Network Fault Tolerance configuration gets lost during the replacement. You will need to configure it on each server after the upgrade.
- Enable PortFast on all switch ports that are connected to Cisco Unified Communications Manager servers. With Portfast enabled, the switch immediately brings a port from the blocking state into the forwarding state by eliminating the forwarding delay (the time that a port waits before changing from its Spanning-Tree Protocol (STP) learning and listening states to the forwarding state).

Table 3 Network Configuration Information

Parameter and Your Entry	Description
DHCP status: _____	Dynamic Host Configuration Protocol status. If DHCP is not enabled, you must enter a hostname, IP Address, IP Mask, and Gateway.
DNS Enabled: _____	DNS status. When DNS is not enabled, you should only enter IP addresses (not hostnames) for all network devices in your Cisco Unified Communications network.
DNS Primary: _____._____._____._____	The IP address of the primary DNS server that Cisco Unified Communications Manager contacts first when it attempts to resolve host names. Consider this setting as required if DNS is enabled.
DNS Secondary: _____._____._____._____	The IP address of the secondary DNS server that Cisco Unified Communications Manager will attempt to connect if the primary DNS server fails.
Domain: _____	The name of the domain in which this machine is located. Consider this setting as required if DNS is enabled.
Gateway Address: _____._____._____._____	The IP address of the default gateway, which is a network point that acts as an entrance to another network. Outbound packets get sent to the gateway that will forward them to their final destination. If you do not have a gateway, you must still fill in this field by setting it to 255.255.255.255. Not having a gateway may limit you to communicating only with devices on your subnet.
Hostname: _____	A name that represents an alias that is assigned to an IP address to identify it. Consider this setting as required if DHCP is disabled.
IP Address: _____._____._____._____	The IP address of this machine. It uniquely identifies the server on this network. Ensure that another machine in this network is not using this IP address. Consider this setting as required is DHCP is disabled.

Table 3 Network Configuration Information (continued)

Parameter and Your Entry	Description
IP Mask: _____._____._____._____	The IP subnet mask of this machine. The subnet mask together with the IP address defines the network address and the host address.
NIC Speed: _____	The speed of the server network interface card (NIC) in megabits per second.
NIC Duplex: _____	The duplex setting of the server NIC.
MTU size	Maximum transmission unit (MTU): the largest packet, in bytes, that this host will transmit on the network.
NTP Server: _____ _____._____._____._____	The hostname or IP address of the NTP server with which you want to keep time synchronization. Consider this setting as required if you enabled the system to be an NTP client.

Related Topics

- [Server or Cluster Replacement Preparation Checklist, page 2](#)
- *Cisco Unified Communications Operating System Administration Guide*

Recording SMTP Settings

Follow this procedure to record the SMTP server setting, which specifies the hostname or IP address of the SMTP host that is used for outbound e-mail.

Procedure

-
- Step 1** In Cisco Unified Communications Operating System Administration, navigate to **Settings > SMTP**.
- Step 2** Record IP address or hostname of the SMTP server.
-

Recording the Hostname and Timezone Settings

Follow this procedure to record the hostname and timezone settings.

Procedure

-
- Step 1** In Cisco Unified Communications Operating System Administration, navigate to **Show > System**.
- Step 2** Record the settings in the following fields:
- Host Name—The unique host name of the server
 - Time Zone—The local time zone and offset from Greenwich Mean Time (GMT)
-

Verifying DNS Registration

If you use DNS, verify that all servers to be replaced are registered in DNS properly.

Procedure

- Step 1** Open a command prompt.
- Step 2** To ping each server by its DNS name, enter **ping <DNS name>**.
- Step 3** To look up each server by IP address, enter **nslookup <IP address>**.
-

Related Topics

[Server or Cluster Replacement Preparation Checklist, page 2](#)

Determining Registration Counts by Using RTMT

Record the number of registered devices, including the numbers of registered phones and gateways, by using the Cisco Unified Communications Manager Real Time Monitoring Tool (RTMT).

Procedure

- Step 1** Download and install the Cisco Unified Communications Manager Real Time Monitoring Tool (RTMT) by choosing **Application > Plugins** from Cisco Unified Communications Manager Administration, clicking **Find**, and clicking the **Download** link next to the appropriate RTMT installer.
- If you are planning to install the RTMT tool on a computer that is running the Microsoft Windows operating system, click the **Download** link for the Cisco Unified Communications Manager Real Time Monitoring Tool-Windows. If you are planning to install the RTMT tool on a computer that is running the Linux operating system, click the **Download** link for the Cisco Unified Communications Manager Real Time Monitoring Tool-Linux.
- Step 2** Open RTMT.
- Step 3** Perform one of the following tasks:
- In the Quick Launch Channel, click the **CallManager** tab, click the **View** tab, click the **Device** category, and click the **Device** icon.
 - Choose **CallManager > Monitor > Device Summary**.
- Step 4** For each Cisco Unified Communications Manager node, record the number for each device type that is displayed, including the numbers of registered phones, FXS, FXO, T1Cas, PRI, MOH, MTP, CFB, XCODE, and H323 Gateways.
-

Related Topics

- [Server or Cluster Replacement Preparation Checklist, page 2](#)
- [Post-Replacement Checklist, page 29](#)
- *Cisco Unified Serviceability Administration Guide*

Recording Critical Service Status

Record all the critical services and their status by using the Cisco Unified Communications Manager Real Time Monitoring Tool (RTMT).

Procedure

- Step 1** Perform one of the following tasks:
- In the Quick Launch Channel, click the **System** tab, click the **View** tab, click the **Server** category, and click the **Critical Services** icon.
 - Choose **System > Server > Critical Services**.
- Step 2** Record the status of all critical services for each node in the cluster.
-

Related Topics

- [Server or Cluster Replacement Preparation Checklist, page 2](#)
- [Post-Replacement Checklist, page 29](#)
- *Cisco Unified Serviceability Administration Guide*

Locating System Errors by Using Syslog Viewer

Using the Syslog viewer in the Cisco Unified Communications Manager Real Time Monitoring Tool (RTMT), locate any events that have a severity of Error or higher.

Procedure

- Step 1** Open RTMT and perform one of the following tasks:
- In the Quick Launch Channel, click the **System** tab, click the **Tools** tab; then click the **SysLog Viewer** icon.
 - Choose **System > Tools > SysLog Viewer > Open SysLog Viewer**.
- Step 2** From the Select a Node drop-down list box, choose the server where the logs that you want to view are stored.
- Step 3** Double-click the Application Logs folder.
- Step 4** Locate events with a severity of Error or higher.
- Step 5** Review each log to locate system-affecting errors.
-

Related Topics

- [Server or Cluster Replacement Preparation Checklist, page 2](#)
- [Post-Replacement Checklist, page 29](#)
- *Cisco Unified Serviceability Administration Guide*

Recording Trace and Log Central Job Details

Record the details of all Trace and Log Central jobs.

Procedure

- Step 1** Open RTMT and perform one of the following tasks:
- In the Quick Launch Channel, click the System tab, click the **Tools** tab; then, click the **Job Status** icon.
 - Choose **System > Tools > Trace > Job Status**.
- Step 2** Double click each scheduled job and record the details that display for each job in the Show Detail dialog box.
-

Related Topics

- [Server or Cluster Replacement Preparation Checklist, page 2](#)
- *Cisco Unified Serviceability Administration Guide*

Accessing CDR Management Configuration

Record CDR Management configuration and destinations, if applicable.

You use the CDR Management Configuration window to set the amount of disk space to allocate to call detail record (CDR) and call management record (CMR) files, configure the number of days to preserve files before deletion, and configure up to three billing application server destinations for CDRs. The CDR repository manager service repeatedly attempts to deliver CDR and CMR files to the billing servers that you configure on the CDR Management Configuration window until it delivers the files successfully, until you change or delete the billing application server on the CDR Management Configuration window, or until the files fall outside the preservation window and are deleted.

Procedure

- Step 1** From Cisco Unified Serviceability, choose **Tools > CDR Management**.
The CDR Management Configuration window displays.
- Step 2** Record the General Parameters and the Billing Application Server Parameters.
-

Related Topics

- [Server or Cluster Replacement Preparation Checklist, page 2](#)
- *Cisco Unified Serviceability Administration Guide*

Determining System Configuration Counts

From Cisco Unified Communications Manager Administration, obtain counts of each of the items that are configured on the system that you want to verify after the replacement. Some examples of items to count follow:

- Phones
- Gateways
- Trunks
- Users
- Route patterns
- CTI ports
- CTI route points

Procedure

-
- Step 1** In Cisco Unified Communications Manager Administration, access the windows for each item that you want to count and click **Find** without entering any search parameters. Some examples follow:
- Find and List Phones (**Device > Phone**)
 - Find and List Gateway (**Device > Gateway**)
 - Find and List Trunks (**Device > Trunk**)
 - Find and List Route Patterns (**Call Routing > Route/Hunt > Route Pattern**)
 - Find and List Users (**User Management > End Users**)
 - Find and List Application Users (**User Management > Application Users**)
- Step 2** Record the number of each of the items (devices, route patterns, and users).
-

Related Topics

- [Server or Cluster Replacement Preparation Checklist, page 2](#)
- [Post-Replacement Checklist, page 29](#)
- *Cisco Unified Communications Manager Administration Guide*

Firmware Information

Record all of the phone loads and device types that display on the Firmware Load Information window.

Procedure

-
- Step 1** In Cisco Unified Communications Manager Administration, choose **Device > Device Settings > Firmware Load Information**.
- The Firmware Load Information window displays.
- Step 2** Record all the phone loads and device types that display.



Note If you have custom device types that do not ship with Cisco Unified Communications Manager, make sure that you have the appropriate COP files, so you can reinstall them.

Related Topics

- [Server or Cluster Replacement Preparation Checklist, page 2](#)
- [Post-Replacement Checklist, page 29](#)
- *Cisco Unified Communications Manager Administration Guide*

Obtaining System Version Information

Compare the system version on each node in your cluster by using Cisco Unified Communications Operating System Administration.

Verify that you have DVDs with that version. If you have a service release, you need media for base image and the service release.

Procedure

-
- Step 1** From the Cisco Unified Communications Operating System Administration window, navigate to **Show > System**.
The System Status window displays.
- Step 2** Make a note of the value that is displayed in the Product Version field.
-

Related Topics

- [Server or Cluster Replacement Preparation Checklist, page 2](#)
- [Post-Replacement Checklist, page 29](#)
- *Cisco Unified Communications Operating System Administration Guide*

Replacing a Single Server or Cluster



Caution

Because this process is designed to work as a server replacement, you must perform it in the live environment. Cisco does not recommend doing this process on a “dead net” because a duplication of entire network environment is required, which is highly risky.

This section provides checklists of the steps that are required to replace a single server or a cluster:

- If you are replacing an entire cluster, replace the servers in the order that is described in [Table 4](#).
- If you are replacing a publisher node in a cluster, or a single server that is not part of a cluster, follow the instructions in the [“Replacing the Publisher Node” section on page 14](#).

- If you are replacing one or more subscriber nodes or dedicated TFTP servers, follow the instructions in the [“Replacing a Subscriber or Dedicated TFTP Server Node”](#) section on page 15 for each server.

Table 4 **Cluster Replacement Process Overview**

	Task	For More Information
Step 1	Replace the publisher node.	“Replacing the Publisher Node” section on page 14
Step 2	Replace any dedicated TFTP servers or other non-Cisco Unified Communications Manager cluster nodes.	“Replacing a Subscriber or Dedicated TFTP Server Node” section on page 15
Step 3	Replace all backup subscriber nodes.	“Replacing a Subscriber or Dedicated TFTP Server Node” section on page 15
Step 4	Replace all primary subscriber nodes.	“Replacing a Subscriber or Dedicated TFTP Server Node” section on page 15
Step 5	Perform any remaining post-replacement tasks in the “Post-Replacement Checklist” section on page 29.	“Post-Replacement Checklist” section on page 29

Replacing the Publisher Node

Complete the following tasks to replace the Cisco Unified Communications Manager publisher server. If you are replacing a single server that is not part of a cluster, follow this procedure to replace your server.

Follow the references in the For More Information column to get more information about a step.

Table 5 *Replacing the Publisher Node Process Overview*

	Description	For More Information
Step 1	Perform the tasks in the “Server or Cluster Replacement Preparation Checklist” section on page 2.	“Server or Cluster Replacement Preparation Checklist” section on page 2
Step 2	Gather the necessary information about the old publisher server.	“Gathering System Configuration Information to Replace or Reinstall a Server” section on page 4
Step 3	Back up the publisher server to a remote SFTP server by using Disaster Recovery System (DRS) and verify that you have a good backup.	“Creating a Backup File” section on page 16
Step 4	Get new licenses of all the license types before system replacement.	Get new licenses of all the license types: Software License Feature, CCM Node License Feature, and Phone License Feature. You only need a new license if you are replacing the publisher node. “Obtaining a License File” section on page 19.
Step 5	Shut down and turn off the old server.	
Step 6	Connect the new server.	
Step 7	Install the same Cisco Unified Communications Manager release on the new server that was installed on the old server, including any Engineering Special releases. Configure the server as the publisher server for the cluster.	“Installing Cisco Unified Communications Manager on the New Publisher Server” section on page 19
Step 8	Restore backed-up data to the publisher server by using DRS.	“Restoring a Backup File” section on page 28
Step 9	Reboot all nodes in the cluster, starting with the subscriber nodes. Reboot the publisher node after all subscriber nodes finish rebooting. If the server is not in a cluster, then reboot the server.	
Step 10	Upload all of the new license files to the publisher server.	Upload new license files for all of the license types: Software License Feature, CCM Node License Feature, and Phone License Feature. “Uploading a License File” section on page 26
Step 11	Delete all invalid license files (those based on the old server MAC address).	“Deleting Invalid License Files” section on page 27
Step 12	Perform the post-replacement tasks in the “Post-Replacement Checklist” section on page 29.	

Replacing a Subscriber or Dedicated TFTP Server Node

Complete the following tasks to replace a subscriber node or dedicated TFTP server (or another server type that is not a Cisco Unified Communications Manager server). A dedicated TFTP server is a node with Cisco Unified Communications Manager installed but with the Cisco Unified Communications Manager service disabled. The TFTP service runs as a dedicated TFTP server for the cluster.

If you are also replacing the publisher node, you must replace it before replacing or reinstalling any other nodes. If the cluster uses backup subscriber nodes, replace or reinstall all backup subscriber nodes before replacing or reinstalling primary subscriber nodes. For more information about cluster replacement, see the [“Replacing a Single Server or Cluster”](#) section on page 12.

You can replace all backup subscriber nodes at the same time if this does not cause outages or oversubscription of primary subscriber nodes. You can replace all primary subscriber nodes at the same time if this does not cause outages or oversubscription of backup subscriber nodes.

Follow the references in the For More Information column to get more information about a step.

Table 6 *Replacing a Subscriber Node or Dedicated TFTP Server Process Overview*

	Description	For More Information
Step 1	Gather the necessary information about the old server.	“Gathering System Configuration Information to Replace or Reinstall a Server” section on page 4
Step 2	If you are getting the system time from an NTP server, verify that the publisher node can synchronize with the NTP server before you install a subsequent node.	“Verifying Publisher NTP Connectivity” section on page 19
Step 3	Shut down and turn off the old server.	
Step 4	Connect the new server.	
Step 5	Install the same Cisco Unified Communications Manager release on the new server that was installed on the old server, including any Engineering Special releases. Configure the new server to use the same configuration information as the old server. For more information, see the “Gathering System Configuration Information to Replace or Reinstall a Server” section on page 4.	“Installing Cisco Unified Communications Manager on a New Subscriber Server” section on page 23
Step 6	Restore backed up data to the node by using DRS.	“Restoring a Backup File” section on page 28
Step 7	Reboot the new server.	
Step 8	Verify that the new server has the same number and status for all Critical services that you gathered before replacing the server.	“Server or Cluster Replacement Preparation Checklist” section on page 2
Step 9	Verify that the db Replicate state has a value of 2. This indicates that the database is set up on this node.	“Post-Replacement Checklist” section on page 29
Step 10	Perform the post-replacement tasks in the “Post-Replacement Checklist” section on page 29.	

Sections that reference this section

- [Replacing the Publisher Node](#), page 14
- [Replacing a Subscriber or Dedicated TFTP Server Node](#), page 15

Creating a Backup File

The following sections describe how to set up and run a backup before an upgrade. Refer to the *Disaster Recovery System Administration Guide* for more information.

If you are recovering or replacing a server, you can skip this section on creating backups and restore the server from the most recent backup that is available.

Sections that reference this section

- [Replacing the Publisher Node, page 14](#)
- [Replacing a Subscriber or Dedicated TFTP Server Node, page 15](#)

Supported Features and Components

You can back up and restore the features and subcomponents that are shown in the following table. For each feature that you choose, the system backs up all its subcomponents automatically.

Table 7 Supported Features and Components

Feature	Components
CCM—Cisco Unified Communications Manager	Cisco Unified Communications Manager (version 6.x) database (CMDB)
	Platform
	Cisco Unified Serviceability
	Music On Hold (MOH)
	Cisco Emergency Responder (CER)
	Bulk Tool (BAT)
	Preference
	Phone device files (TFTP)
	syslogagt (SNMP syslog agent)
	cdpagent (SNMP cdp agent)
	tct (trace collection tool)
	Call Detail Records (CDR)
	CDR Analysis and Reporting (CAR)

Configuring Features to Back Up

Before you can schedule or start a backup job, you must configure the features that you want to back up.



Note

Changing a backup feature changes it for both manual and scheduled backups.

Perform the following steps to choose the features that you want to back up.

Procedure

-
- Step 1** Navigate to the Disaster Recovery System. Log in to Cisco Unified Communications Manager Administration, choose **Disaster Recovery System** from the **Navigation** menu in the upper, right corner of the Cisco Unified Communications Manager Administration window, and click **Go**.
- The Disaster Recovery System Logon window displays.
- Step 2** Log in to the Disaster Recovery System by using the same Administrator user name and password that you use for Cisco Unified Communications Operating System Administration.
- Step 3** Navigate to **Backup>Configure Features**.
- Step 4** From the list of available features, choose the feature or features that you want to include in the backup and click **Save**. You must choose at least one feature.
- Step 5** Continue with the next procedure for configuring a storage location.
-

Configuring a Storage Location

Before using the Disaster Recovery System, you must configure the location where you want the backup file to be stored. Perform the following steps to configure the storage location.

Procedure

-
- Step 1** Navigate to the Disaster Recovery System. Log in to Cisco Unified Communications Manager Administration, choose **Disaster Recovery System** from the **Navigation** menu in the upper, right corner of the Cisco Unified Communications Manager Administration window, and click **Go**.
- The Disaster Recovery System Logon window displays.
- Step 2** Log in to the Disaster Recovery System by using the same Administrator user name and password that you use for Cisco Unified Communications Operating System Administration.
- Step 3** Navigate to **Backup>Storage Location**. The Storage Location window displays.



Note You can configure the number of backup sets that are stored on a network directory.

- Step 4** Select the **Network Directory** option to store the backup data on a networked drive that is accessed through an SFTP connection.
- Step 5** Enter the following required information:
- **Server name:** Name or IP address of the network server
 - **Path name:** Path name for the directory where you want to store the backup file
 - **User name:** Valid username for an account on the remote system
 - **Password:** Valid password for the account on the remote system



Note You must have access to an SFTP server to configure a network storage location. The SFTP path must exist prior to the backup. Ensure that the account that is used to access the SFTP server has write permission for the selected path.

Step 6 To update these settings, click **Save**.



Note For network directory backups, after you click the **Save** button, the DRS Master Agent will validate the selected SFTP server. If the user name, password, server name, or directory path is invalid, the save will fail.

Step 7 Continue with either a manual or a scheduled backup.

Starting a Manual Backup

You can manually start a backup of the features that you choose on the **Configure Features** menu. Perform the following steps to start a manual backup.

Procedure

Step 1 Navigate to the Disaster Recovery System. Log in to Cisco Unified Communications Manager Administration, choose **Disaster Recovery System** from the **Navigation** menu in the upper, right corner of the Cisco Unified Communications Manager Administration window, and click **Go**.

The Disaster Recovery System Logon window displays.

Step 2 Log in to the Disaster Recovery System by using the same Administrator user name and password that you use for Cisco Unified Communications Operating System Administration.

Step 3 Navigate to **Backup>Manual Backup**. The Manual Backup window displays.

Step 4 Make sure the features that you want to back up are chosen. To choose other features, see the [“Configuring Features to Back Up” section on page 16](#).



Note Ensure all servers in the cluster are running the same version of Cisco Unified Communications Manager and are reachable through the network. Servers that are not running at the time of the scheduled backup will not get backed up.

Step 5 To begin the manual backup, click **Start Backup**.

Step 6 Make sure that you have configured the backup storage location. See the [“Configuring a Storage Location” section on page 17](#).

Checking the Status of the Current Backup Job

Perform the following steps to check the status of the current backup job.

Procedure

Step 1 Navigate to the Disaster Recovery System. Log in to Cisco Unified Communications Manager Administration, choose **Disaster Recovery System** from the **Navigation** menu in the upper, right corner of the Cisco Unified Communications Manager Administration window, and click **Go**.

The Disaster Recovery System Logon window displays.

- Step 2** Log in to the Disaster Recovery System by using the same Administrator user name and password that you use for Cisco Unified Communications Operating System Administration.
- Step 3** Navigate to **Backup>Current Status**. The Backup Status window displays.
- Step 4** To view the backup log file, click the log filename link.
- Step 5** To cancel the current backup, click **Cancel Backup**.



Note The backup cancels after the current component completes its backup operation.

Obtaining a License File

If you have to replace the first node in your Cisco Unified Communications Manager cluster, you must open a case with the licensing team to obtain a license for your replacement server. Contact the licensing team at licensing@cisco.com. After you receive the new license file, upload the software license file as described in “[Uploading a License File](#)” section on page 26.



Note

Replacing a motherboard on the first node also requires a new license file.

Sections that reference this section

- [Replacing the Publisher Node, page 14](#)

Verifying Publisher NTP Connectivity

If you are getting the system time from an NTP server, verify that the publisher node can synchronize with the NTP server before you install a subscriber node.

To verify the NTP status of the first node, log into the command line interface on the publisher node and enter the following command: `utils ntp status`

For more information, see the *Cisco Unified Communications Operating System Administration Guide*.



Caution

If the first node fails to synchronize with an NTP server, installation of a subsequent node can also fail.

Installing Cisco Unified Communications Manager on the New Publisher Server

Use this procedure to install Cisco Unified Communications Manager on the new publisher server. For more information about installing this product, refer to the document, *Installing Cisco Unified Communications Manager*.

Procedure

-
- Step 1** Insert the installation DVD into the tray and restart the server, so it boots from the DVD. After the server completes the boot sequence, the DVD Found window displays.
- Step 2** To perform the media check, choose **Yes** or, to skip the media check, choose **No**.
The media check checks the integrity of the DVD. If your DVD passed the media check previously, you might choose to skip the media check.
- Step 3** If you choose **Yes** to perform the media check, the system installer performs the media check and displays the Media Check Result window. Perform these tasks:
- If the Media Check Result displays Pass, choose **OK** to continue the installation.
 - If the media fails the media check, either download another copy of the software from Cisco.com or obtain another disc directly from Cisco.

- Step 4** The system installer performs the following hardware checks to ensure that your system is correctly configured. If the installer makes any changes to your hardware configuration settings, you will get prompted to restart your system. Leave the DVD in the drive during the restart.
- First, the installation process checks for the correct drivers, and you may see the following warning:

```
No hard drives have been found. You probably need to manually choose device drivers
for install to succeed. Would you like to select drivers now?
```

To continue the installation, choose **Yes**.
 - The installation next checks to see whether you have a supported hardware platform. If your server does not meet the exact hardware requirements, the installation process fails with a critical error. If you think this is not correct, capture the error and report it Cisco support.
 - The installation process next verifies RAID configuration and BIOS settings.



Note If this step repeats, choose **Yes** again.

After the hardware checks complete, the Product Deployment Selection window displays.

- Step 5** In the Product Deployment Selection window, select **Cisco Unified Communications Manager**; then, choose **OK**.
- Step 6** If software is currently installed on the server, the Overwrite Hard Drive window opens and displays the current software version on your hard drive and the version on the DVD. To continue with the installation, choose **Yes**, or choose **No** to cancel.



Caution If you choose **Yes** on the **Overwrite Hard Drive** window, all existing data on your hard drive gets overwritten and destroyed.

- Step 7** The Platform Installation Wizard window displays.
- Step 8** To configure the platform now, choose **Proceed**.
- Step 9** In the Basic Install window, choose **Continue** to install the software version on the DVD.
- Step 10** When the Timezone Configuration displays, choose the appropriate time zone for the server and then choose **OK**.
The Auto Negotiation Configuration window displays.

Step 11 The installation process allows you to automatically set the speed and duplex settings of the Ethernet network interface card (NIC) by using automatic negotiation. You can change this setting after installation.

- To enable automatic negotiation, choose **Yes** and continue with [Step 13](#).
The MTU Configuration window displays.



Note To use this option, your hub or Ethernet switch must support automatic negotiation.

- To disable automatic negotiation, choose **No** and continue with [Step 12](#).
The NIC Speed and Duplex Configuration window displays.

Step 12 If you chose to disable automatic negotiation, manually choose the appropriate NIC speed and duplex settings now and choose **OK** to continue.

The MTU Configuration window displays.

Step 13 In the MTU Configuration window, you can change the MTU size from the operating system default. The maximum transmission unit (MTU) represents the largest packet, in bytes, that this host will transmit on the network. If you are unsure of the MTU setting for your network, use the default value, which is 1500 bytes.



Caution Configuring the MTU size incorrectly can affect your network performance.

- To accept the default value (1500 bytes), choose **No**.
- To change the MTU size from the operating system default, choose **Yes**, enter the new MTU size, and choose **OK**.

The DHCP Configuration window displays.

Step 14 For network configuration, you can choose to either set up static network IP address for the node or to use Dynamic Host Configuration Protocol (DHCP).

- If you have a DHCP server that is configured in your network and want to use DHCP, choose **Yes** and continue with [Step 17](#).

The Administrator Login Configuration window displays.

- If you want to configure static IP address for the node, choose **No** and continue with [Step 15](#).

The Static Network Configuration window displays.

Step 15 If you chose not to use DHCP, enter your static network configuration values and choose **OK**. See [Table 3](#) for field descriptions.

The DNS Client Configuration window displays.

Step 16 To enable DNS, choose **Yes**, enter your DNS client information, and choose **OK**. See [Table 3](#) for field descriptions.

The Administrator Login Configuration window displays.

Step 17 Enter your Administrator login and password from [Table 2](#).

The Certificate Signing Request Information window displays.

Step 18 Enter your certificate signing request information and choose **OK**.

The First Node Configuration window displays.

Step 19 To configure this server as the first Cisco Unified Communications Manager node, choose **Yes**.
The Network Time Protocol Client Configuration window displays.

Step 20 Choose whether you want to configure an external NTP server or manually configure the system time.



Note Cisco recommends that you use an external NTP server to ensure accurate system time on the first node. Ensure the external NTP server is stratum 9 or higher (meaning stratum 1-9). Subsequent nodes in the cluster will get their time from the first node.

- To set up an external NTP server, choose **Yes** and enter the IP address, NTP server name, or NTP server pool name for at least one NTP server. You can configure up to five NTP servers, and Cisco recommends that you use at least three. Choose **Proceed** to continue with the installation.

The system contacts an NTP server and automatically sets the time on the hardware clock.



Note If you already entered the network configuration information and the system rebooted (a Skip installation), the Test button displays. You can choose **Test** to check whether the NTP servers are accessible.

- To manually configure the system time, choose **No** and enter the appropriate date and time to set the hardware clock. Choose **OK** to continue with the installation.

The Database Access Security Configuration window displays.

Step 21 Enter the Database Access Security password from [Table 2](#).

The SMTP Host Configuration window displays.

Step 22 If you want to configure an SMTP server, choose **Yes** and enter the SMTP server name.



Note You must configure an SMTP server to use certain platform features; however, you can also configure an SMTP server later by using the operating system GUI or the command line interface.

Step 23 Choose **OK**.

The Platform Configuration Confirmation window displays.

Step 24 To continue with the installation, choose **OK**.

The Application User Password Configuration window displays.



Note If you need to change one of your previous entries, choose **Back**, make the change, and continue with the installation.

Step 25 Enter the Application User Password from [Table 2](#) and confirm the password by entering it again.

Step 26 Choose **OK**.

The system installs and configures the software. The DVD drive ejects, and the server reboots. Do not reinsert the DVD.

Step 27 When the installation process completes, you get prompted to log in by using the Administrator account and password.

Step 28 Complete the rest of the tasks that are listed in the “[Replacing the Publisher Node](#)” section on page 14.

Installing Cisco Unified Communications Manager on a New Subscriber Server

Use this procedure to install Cisco Unified Communications Manager on a new subscriber server.

Procedure

Step 1 If you configured Network Time Protocol (NTP) on the publisher node, ensure that the publisher node is synchronized with an NTP server before you install a subscriber node. From the Command Line Interface on the publisher node, enter the command **utils ntp status**. Ensure that the printout indicates that the node is synchronized with an NTP server.



Note If the first node is not synchronized with an NTP server, installation of the subsequent node will fail.

Step 2 Insert the installation DVD into the tray and restart the server, so it boots from the DVD. After the server completes the boot sequence, the DVD Found window displays.

Step 3 To perform the media check, choose **Yes** or, to skip the media check, choose **No**.

The media check checks the integrity of the DVD. If your DVD has passed the media check previously, you might choose to skip the media check.

Step 4 If you choose **Yes** to perform the media check, the system installer performs the media check and displays the Media Check Result window. Perform these tasks:

- a. If the Media Check Result displays Pass, choose **OK** to continue the installation.
- b. If the media fails the media check, either download another copy of the software from Cisco.com or obtain another disc directly from Cisco.

Step 5 The system installer performs the following hardware checks to ensure that your system is correctly configured. If the installer makes any changes to your hardware configuration settings, you will get prompted to restart your system. Leave the DVD in the drive during the reboot.

- First, the installation process checks for the correct drivers, and you may see the following warning:

```
No hard drives have been found. You probably need to manually choose device drivers
for install to succeed. Would you like to select drivers now?
```

To continue the installation, choose **Yes**.

- The installation next checks to see whether you have a supported hardware platform. If your server does not meet the exact hardware requirements, the installation process fails with a critical error. If you think this is not correct, capture the error and report it Cisco support.
- The installation process next verifies RAID configuration and BIOS settings.



Note If this step repeats, choose **Yes** again.

After the hardware checks complete, Product Deployment Selection window displays.

- Step 6** In the Product Deployment Selection window, select **Cisco Unified Communications Manager**; then, choose **OK**.
- Step 7** If software is currently installed on the server, the Overwrite Hard Drive window opens and displays the current software version on your hard drive and the version on the DVD. Choose **Yes** to continue with the installation or **No** to cancel.



Caution If you choose **Yes** on the **Overwrite Hard Drive** window, all existing data on your hard drive gets overwritten and destroyed.

- Step 8** The Platform Installation Wizard window displays.
- Step 9** To configure the platform now, choose **Proceed**.
- Step 10** In the Basic Install window, choose **Continue** to install the software version on the DVD.
- Step 11** When the Timezone Configuration displays, choose the appropriate time zone for the server and then choose **OK**.
- The Auto Negotiation Configuration window displays.
- Step 12** The installation process allows you to automatically set the speed and duplex settings of the Ethernet network interface card (NIC) by using automatic negotiation. You can change this setting after installation.
- To enable automatic negotiation, choose **Yes** and continue with [Step 14](#).
- The MTU Configuration window displays.



Note To use this option, ensure that your hub or Ethernet switch supports automatic negotiation.

- To disable automatic negotiation, choose **No** and continue with [Step 13](#).
- The NIC Speed and Duplex Configuration window displays.
- Step 13** If you chose to disable automatic negotiation, manually choose the appropriate NIC speed and duplex settings now and choose **OK** to continue.
- The MTU Configuration window displays.
- Step 14** In the MTU Configuration window, you can change the MTU size from the operating system default.
- The maximum transmission unit (MTU) represents the largest packet, in bytes, that this host will transmit on the network. If you are unsure of the MTU setting for your network, use the default value, which is 1500 bytes.



Caution Configuring the MTU size incorrectly can affect your network performance.

- To accept the default value (1500 bytes), choose **No**.
 - To change the MTU size from the operating system default, choose **Yes**, enter the new MTU size, and choose **OK**.
- The DHCP Configuration window displays.
- Step 15** For network configuration, you can choose to either set up static network IP address for the node or to use Dynamic Host Configuration Protocol (DHCP).

- If you have a DHCP server that is configured in your network and want to use DHCP, choose **Yes** and continue with [Step 17](#).

The Administrator Login Configuration window displays.

- If you want to configure static IP address for the node, choose **No** and continue with [Step 15](#).

The Static Network Configuration window displays.

Step 16 If you chose not to use DHCP, enter your static network configuration values and choose **OK**. See [Table 3](#) for field descriptions.

The DNS Client Configuration window displays.

Step 17 To enable DNS, choose **Yes**, enter your DNS client information, and choose **OK**. See [Table 3](#) for field descriptions.

The Administrator Login Configuration window displays.

Step 18 Enter your Administrator login and password from [Table 2](#).

The Certificate Signing Request Information window displays.

Step 19 Enter your certificate signing request information and choose **OK**.

The First Node Configuration window displays.

Step 20 To configure this server as a subsequent node in the cluster, choose **No**.

The First Node Configuration window displays.



Caution

You must configure a subsequent node on the first node by using Cisco Unified Communications Manager Administration before you install the subsequent node. For more information, see the *Cisco Unified Communications Manager Administration Guide*.

Step 21 On the First Node Configuration window, read the Warning and make sure that you have correctly configured the first node. To continue with the installation of the subsequent node, choose **OK**.

The Network Connectivity Test Configuration window displays.

Step 22 During installation of a subsequent node, the system checks to ensure that the subsequent node can connect to the first node.

- To pause the installation after the system successfully verifies network connectivity, choose **Yes**.
- To continue the installation with a pause, choose **No**.

The First Node Access Configuration window displays.

Step 23 Enter the first node connectivity information to enable this subscriber node to connect to the subscriber node.

If you chose to pause the system after the system successfully verified network connectivity, the Successful Connection to First Node window displays. Choose **Continue**.



Note

If the network connectivity test fails, the system always stops and allows you to go back and reenter the parameter information.

The SMTP Host Configuration window displays.

Step 24 If you want to configure an SMTP server, choose **Yes** and enter the SMTP server name.



Note You must configure an SMTP server to use certain operating system features; however, you can also configure an SMTP server later by using the operating system GUI or the command line interface.

The Platform Configuration Confirmation window displays.

- Step 25** To start installing the software, choose **OK**, or if you want to change the configuration, choose **Back**.
 - Step 26** When the installation process completes, you get prompted to log in by using the Administrator account and password.
 - Step 27** Complete the rest of the tasks in the [“Replacing a Subscriber or Dedicated TFTP Server Node” section on page 15](#).
-

Sections that reference this section

- [Replacing a Subscriber or Dedicated TFTP Server Node, page 15](#)

Uploading a License File

Use the following procedure to upload a license file to the Cisco Unified Communications Manager server with the matching MAC address that is provided when a license file is requested. For information about obtaining a license file, see the [“Obtaining a License File” section on page 19](#). The Cisco Unified Communications Manager server where the license file is loaded takes on the functionality of the license manager.



Note Upload the license file only on the first node of Cisco Unified Communications Manager cluster.

Procedure

- Step 1** Choose **System > License > Upload License File**.
The License File Upload window displays.
- Step 2** The Existing License Files drop-down list box displays the license files that are already uploaded to the server.



Note To view the file content of any existing files, choose the file from the drop-down list box and click **View File**.

- Step 3** To choose a new license file to upload, click **Upload License File**.
The Upload File window displays.
- Step 4** Browse and choose a license file to upload to the server.



Note The format of the license file that you receive specifies CCM<timestamp>.lic. If you retain the .lic extension, you can rename the license file. You cannot use the license if you edit the contents of the file in any way.

Step 5 Click **Upload License File**.

After the upload process completes, the Upload Result file displays.

Step 6 Click **Close**.

Step 7 In the License File Upload window, the status of the uploaded file displays.



Note The system uploads the license file into the database only if the version that is specified in the license file is greater than or equal to the Cisco Unified Communications Manager version that is running in the cluster. If the version check fails, an alarm occurs, and you should get a new license file with the correct version. The system bases the version check only on major releases.

Step 8 Restart the Cisco CallManager service. For information on restarting services, refer to the *Administration Guide for Cisco Unity Connection Serviceability*.

Sections that reference this section

- [Replacing the Publisher Node, page 14](#)

Deleting Invalid License Files

The license files that get restored to the server by Disaster Recovery System are invalid because they are bound to the MAC address of the old server. To delete all invalid license files from your server, follow these steps:

Step 1 Obtain the MAC address of the new server by running the **show status** CLI command.

The MAC address displays in the field License MAC.

Step 2 View each license file on the server to determine which license files are invalid.

- In Cisco Unified Communications Manager Administration, choose **System > Licensing > License File Upload**.
- Choose a license file from the Existing License Files drop-down list.
- Click the **View File** button.
- The license file MAC address displays in the HOSTID field.
If the license file MAC address does not match the server MAC address, then the license is invalid.
- Record the file name of each invalid license file.
- Repeat this process for each license file on the server.

Step 3 Delete each invalid license file from the server by running the CLI command **file delete license filename**, where *filename* is the name of the license file.

For more information about this command, refer to the document *Command Line Interface Reference Guide for Cisco Unified Communications Solutions*.

Restoring a Backup File

The Restore Wizard takes you through the steps that are required to restore a backup file. To perform a restore, use the procedure that follows.



Caution

Before you restore Cisco Unified Communications Manager, ensure that the Cisco Unified Communications Manager version that is installed on the server matches the version of the backup file that you want to restore.

Procedure

Step 1 Navigate to the Disaster Recovery System. Log in to Cisco Unified Communications Manager Administration, choose **Disaster Recovery System** from the **Navigation** menu in the upper, right corner of the Cisco Unified Communications Manager Administration window, and click **Go**.

The Disaster Recovery System Logon window displays.

Step 2 Log in to the Disaster Recovery System by using the same Administrator user name and password that you use for Cisco Unified Communications Operating System Administration.

Step 3 Navigate to **Restore>Restore Wizard**. The Restore Wizard Step 1 window displays.

Step 4 Choose the **Network Directory** storage location from which you want to restore the file and enter the following required information for the chosen storage location:

- **Server name:** Name or IP address of the network server
- **Path name:** Path name for the directory from which you want to restore the backup data
- **User name:** Valid username for an SFTP account on the remote system
- **Password:** Valid password for the SFTP account on the remote system

Step 5 Click **Next**. The Restore Wizard Step 2 window displays.

Step 6 Choose the backup file that you want to restore.



Note The backup filename indicates the date and time that the system created the backup file.

Step 7 Click **Next**. The Restore Wizard Step 3 window displays.

Step 8 Choose the features that you want to restore.



Note Only the features that were backed up to the file that you chose display.

Step 9 Click **Next**. The Restore Wizard Step 4 window displays.

Step 10 To start restoring the data, click **Restore**.

You get prompted to choose the node to restore.

Step 11 Choose the appropriate node.



Caution

After you choose the node to which you want the data restored, any existing data on that server gets overwritten.

- Step 12** Your data gets restored on the nodes that you chose. To view the status of the restore, see the “[Viewing the Restore Status](#)” section on page 29.



Note Depending on the size of your database and the components that you choose to restore, the system can require 1 hour or more to restore.

Sections that reference this section

- [Replacing the Publisher Node, page 14](#)
- [Replacing a Subscriber or Dedicated TFTP Server Node, page 15](#)

Viewing the Restore Status


To check the status of the current restore job, perform the following steps:

Procedure

- Step 1** Navigate to the Disaster Recovery System. Log in to Cisco Unified Communications Manager Administration, choose **Disaster Recovery System** from the **Navigation** menu in the upper, right corner of the Cisco Unified Communications Manager Administration window, and click **Go**.
- The Disaster Recovery System Logon window displays.
- Step 2** Log in to the Disaster Recovery System by using the same Administrator user name and password that you use for Cisco Unified Communications Operating System Administration.
- Step 3** Navigate to **Restore>Status**. The Restore Status window displays.
- Step 4** To view the restore log file, click the log filename link.

Post-Replacement Checklist

Perform the following tasks after you complete the cluster replacement:

Post-Upgrade Task	Important Notes
<p>Step 1 If your server or cluster ran in secure mode, create a new CTL file and distribute it to all the cluster nodes. Do this step after you finish replacing or reinstalling all the servers that you intend to replace or reinstall.</p>	<p>For information about performing these tasks and about Cisco Unified Communications Manager security, refer to the “Configuring the CTL Client” procedures in the <i>Cisco Unified Communications Manager Security Guide</i>.</p> <p> Caution You must create and distribute a new CTL file, or your secure phones will not work because they cannot register with the replaced Cisco Unified Communications Manager server(s).</p>
<p>Step 2 Using the Cisco Unified Communications Manager Real Time Monitoring Tool (RTMT), make sure that all the registration information values match the values that you recorded before the server replacement.</p>	<p>See the “Determining Registration Counts by Using RTMT” section on page 8.</p>
<p>Step 3 Using the Cisco Unified Communications Manager Real Time Monitoring Tool (RTMT), make sure that all the critical services and their status match those that you recorded before the server replacement.</p>	<p>See the “Recording Critical Service Status” section on page 9.</p>
<p>Step 4 Using the Syslog viewer in the Cisco Unified Communications Manager Real Time Monitoring Tool (RTMT), locate any events that have a severity of Error or higher.</p>	<p>Perform this task to ensure that no system-affecting errors exist on your system.</p> <p>See the “Locating System Errors by Using Syslog Viewer” section on page 9.</p>
<p>Step 5 Using the Syslog viewer in the Cisco Unified Communications Manager Real Time Monitoring Tool (RTMT), check the Replicate_State counter for the Number of Replicates Created and State of Replication object on all nodes. The value on each node should equal 2.</p> <p>This counter represents the state of replication, which includes the following possible values:</p> <ul style="list-style-type: none"> • 0—Initializing. The counter equals 0 when the server is not defined or when the server is defined but the realize template has not completed. • 1—The system created replicates of some tables but not all tables. Cisco recommends that you run <code>utils dbreplication status</code> on the CLI to determine the location and cause of the failure. • 2—Good Replication. • 3—Bad Replication. When the counter displays a value of 3, consider replication in the cluster as bad. It does not mean that replication failed on a particular node. Cisco recommends that you run <code>utils dbreplication status</code> on the CLI to determine the location and cause of the failure. • 4—Replication setup did not succeed. 	<p>To access the appropriate object and counter, use the following procedure:</p> <ol style="list-style-type: none"> 1. Perform one of the following tasks: <ul style="list-style-type: none"> • In the Quick Launch Channel, click System > Performance; then, click the Performance icon. • Choose Performance > Open Performance Monitoring. 2. Double-click the name of the server where you want to add a counter to monitor. 3. Double-click the Number of Replicates Created and State of Replication object. 4. Double-click the Replicate_State counter. 5. Choose the ReplicateCount instance and click Add.

Post-Upgrade Task	Important Notes
Step 6 From Cisco Unified Communications Manager Administration, make sure that the number of phones, gateways, trunks, users, and route patterns that are configured in the database matches the numbers that you recorded before the server replacement.	See the “Determining System Configuration Counts” section on page 11.
Step 7 From the Firmware Load Information window in Cisco Unified Communications Manager Administration, make sure that the phone load type value matches the value that you recorded before the server replacement.	See the “Firmware Information” section on page 11.
Step 8 Reinstall the COP file enablers for any custom device types that do not ship with Cisco Unified Communications Manager.	Then, reboot the cluster and start post-replacement checklist again.
Step 9 Reinstall any locales that were installed on the server.	
Step 10 Compare the system version on each node in your cluster by using Cisco Unified Communications Operating System Administration and make sure that it matches the version that you recorded before the replacement.	See the “Obtaining System Version Information” section on page 12.
Step 11 Reconfigure CDR destinations, if applicable.	See the “Accessing CDR Management Configuration” section on page 10.
Step 12 Reconfigure all Trace and Log Central jobs.	See the “Recording Trace and Log Central Job Details” section on page 10.
Step 13 Perform any system tests that you performed before the replacement and verify that all test calls succeed.	
Step 14 Reconfigure DRS location and schedule, if applicable.	See the “Creating a Backup File” section on page 16.

Upgrading Server Hardware When Upgrading to Cisco Unified Communications Manager Release 8.6(1)

The following sections contain information about upgrading server hardware When Upgrading to Cisco Unified Communications Manager Release 8.6(1):

- [Memory Recommendations for Upgrading to Cisco Unified Communications Manager Release 8.6.1, page 32](#)
- [Upgrading Hard Drives When Upgrading to Cisco Unified Communications Manager Release 8.6\(1\), page 32](#)

Memory Recommendations for Upgrading to Cisco Unified Communications Manager Release 8.6.1

It is strongly recommended that you run Cisco Unified Communications Manager Release 8.6(1) only on servers with at least 4 GB of memory.

Upgrading Hard Drives When Upgrading to Cisco Unified Communications Manager Release 8.6(1)

Follow this procedure to replace 72 GB hard drives with 146 GB hard drives when you upgrade to Cisco Unified Communications Manager Release 8.6(1):

-
- Step 1** Reduce used disk space by following these steps:
- Enter the CLI command **show status**.
If the active partition is 97% full or higher, seriously consider replacing the 72 GB drives with 146 GB drives. Use Real Time Monitoring Tool to monitor disk space usage.
 - If you are running Cisco Unified Communications Manager release 6.x or higher, reduce used disk space by performing these steps:
 - Enter the CLI command **utils diagnose module disk_files** to identify files that you can delete.
 - To delete files that you identified, use the CLI command **file delete**.
 - Enter the CLI command **show status** to see the new disk space usage on the active partition.
- Step 2** Back up the server using Disaster Recovery System.
- Step 3** If you are running Cisco Unified Communications Manager release 5.x, upgrade the server to a 7.x release. If the upgrade fails, switch back to release 5.x and report the issue to Cisco Technical Support.
- Step 4** Upgrade the server to release 8.6(1).
- Step 5** If the upgrade to release 8.6(1) fails due to disk space shortage in /common, as reported by Real Time Monitoring Tool or in the upgrade log file (look for phrases with the word “space” in them, such as “Not enough space on partition to proceed” or “No space left on device”), perform the recommended workaround in [“Workaround for /common: Adjust logging”](#) section on page 33, then go to [Step 4](#).
- If the server originally was running Cisco Unified Communications Manager release 5.x, perform a fresh installation of the same 5.x release, then restore the data using Disaster Recovery System, then go to Step b.

- b. If the server was originally not running Cisco Unified Communications Manager release 6.x or higher and the switchover to release 8.6(1) occurred, then clean up disk space using the procedure in [Step 1](#), then switch back to the previous release.
- c. Order 146 GB hard drives.
- d. When the new hard drives are ready to be installed, perform these steps:
 - Perform a backup of the existing Cisco Unified Communications Manager release using Disaster Recovery System.
 - Install the new hard drives
 - Perform a fresh installation of the existing Cisco Unified Communications Manager release.
 - Restore data to the server using Disaster Recovery System.
 - Go to [Step 3](#).

Step 6 If the upgrade to release 8.6(1) fails for other reasons, contact Cisco Technical Support.

Step 7 If the upgrade to release 8.6(1) succeeds, be sure to run Real Time Monitoring Tool and monitor disk space usage, particularly if the active partition found in [Step 1](#) was already over 97% disk usage.

Workaround for /common: Adjust logging

To change one of the values below, click the right mouse button on the attribute and select **Set Alert/Properties**. Once in the dialog box, click **Next** to open the dialog box for modifying the threshold values.

Before the upgrade:

Step 1 Launch Real Time Monitoring Tool.

Step 2 Select **Alert Central**, then perform the following tasks:

- a. Select **LogPartitionHighWaterMarkExceeded**, note its value and change its threshold value to 60%.
- b. Select **LogPartitionLowWaterMarkExceeded**, note its value and change its threshold value to 50%.

Polling occurs every 5 minutes, so wait for 5-10 minutes, then verify that the required disk space is available. If you want to free up more disk space in the common partition, change **LogPartitionHighWaterMarkExceeded** and **LogPartitionLowWaterMarkExceeded** thread values to lower values (for example, 30% and 20%) again.

After the upgrade finishes, change the threshold fields back their original values. The defaults are 95% for high water mark and 90% for low water mark.

Obtaining Documentation, Obtaining Support, and Security Guidelines

For information on obtaining documentation, obtaining support, providing documentation feedback, security guidelines, and also recommended aliases and general Cisco documents, see the monthly *What's New in Cisco Product Documentation*, which also lists all new and revised Cisco technical documentation, at:

<http://www.cisco.com/en/US/docs/general/whatsnew/whatsnew.html>

CCVP, the Cisco logo, and Welcome to the Human Network are trademarks of Cisco Systems, Inc.; Changing the Way We Work, Live, Play, and Learn is a service mark of Cisco Systems, Inc.; and Access Registrar, Aironet, Catalyst, CCDA, CCDP, CCIE, CCIP, CCNA, CCNP, CCSP, Cisco, the Cisco Certified Internetwork Expert logo, Cisco IOS, Cisco Press, Cisco Systems, Cisco Systems Capital, the Cisco Systems logo, Cisco Unity, Enterprise/Solver, EtherChannel, EtherFast, EtherSwitch, Fast Step, Follow Me Browsing, FormShare, GigaDrive, HomeLink, Internet Quotient, IOS, iPhone, IP/TV, iQ Expertise, the iQ logo, iQ Net Readiness Scorecard, iQuick Study, LightStream, Linksys, MeetingPlace, MGX, Networkers, Networking Academy, Network Registrar, PIX, ProConnect, ScriptShare, SMARTnet, StackWise, The Fastest Way to Increase Your Internet Quotient, and TransPath are registered trademarks of Cisco Systems, Inc. and/or its affiliates in the United States and certain other countries.

Cisco and the Cisco logo are trademarks or registered trademarks of Cisco and/or its affiliates in the U.S. and other countries. To view a list of Cisco trademarks, go to this URL: www.cisco.com/go/trademarks. Third-party trademarks mentioned are the property of their respective owners. The use of the word partner does not imply a partnership relationship between Cisco and any other company. (1110R)

Any Internet Protocol (IP) addresses used in this document are not intended to be actual addresses. Any examples, command display output, and figures included in the document are shown for illustrative purposes only. Any use of actual IP addresses in illustrative content is unintentional and coincidental.

Copyright © 2011 Cisco Systems, Inc. All rights reserved.