

# **Auto reboot after pre-provisioning**

(KX-TGP series)

No. 01-003

March 3 , 2011

Ver.1.0

Panasonic Corporation

## Abstract about this document

This document describe about setting of auto reboot after pre-provisioning. If this configuration is set, TGP reboot automatically after pre-provisioning so that user doesn't need to reboot TGP by manually. This feature is added after firmware version 12.10/22.10.

## Revision history

Date	Version	Revision	Firmware version
Mar. 3, 2011	Ver. 1.0	Initial Release	12.10/22.10 or later

# To set up the server for pre-provisioning

## Until Firmware:12.06/22.06

1. Start up the DHCP server and TFTP server, and configure the settings.
2. Connect the unit to the network, and turn the power on.
  - a. The IP address "192.168.0.16" is assigned to the unit by the DHCP server.
  - b. The unit acquires the TFTP server address "192.168.0.130" from the DHCP server using DHCP server option 66.
  - c. The unit downloads the configuration file for pre-provisioning from the TFTP server:  
tftp://192.168.0.130/KX-TGP500B01.cfg
  - d. The URL of the server where the configuration file for provisioning is stored (provisioning server) is set to the unit:  
http://provisioning.example.com/Panasonic/Config{MAC}.cfg
  - e. When pre-provisioning has completed successfully, the status LED lights in the following order:  
Red > Green > Orange > Red > ...
3. **When the status LED lights as described in step e, turn off the unit's power.**  
When the unit is distributed to end users and started up in real circumstances, provisioning will be performed correctly.

You need to **reboot** the TGP to perform provisioning by manually


## Firmware:12.10/22.10 or later

1. Start up the DHCP server and TFTP server, and configure the settings.
2. Connect the unit to the network, and turn the power on.
  - a. The IP address "192.168.0.16" is assigned to the unit by the DHCP server.
  - b. The unit acquires the TFTP server address "192.168.0.130" from the DHCP server using DHCP server option 66.
  - c. The unit downloads the configuration file for pre-provisioning from the TFTP server:  
tftp://192.168.0.130/KX-TGP500B01.cfg
  - d. The URL of the server where the configuration file for provisioning is stored (provisioning server) is set to the unit:  
http://provisioning.example.com/Panasonic/Config{MAC}.cfg
  - e. When pre-provisioning has completed successfully, the status LED lights in the following order:  
Red > Green > Orange > Red > ...
3. When the status LED lights as described in step e, turn off the unit's power.  
**The unit will restart automatically depending on the configuration file programming (Parameter "OPTION66\_REBOOT").**  
When the unit is distributed to end users and started up in real circumstances, provisioning will be performed correctly.

TGP can reboot automatically by setting **OPTION66\_REBOOT="Y"**.  
(Default : **OPTION66\_REBOOT="N"**)

# [Specific] Until Firmware:12.06/22.06

Configuration file name is example.



# [Specific] Firmware:12.10/22.10 or later

Configuration file name is example.

