

Viewing the PSTN Account Status

1. Press  when the phone is idle, and then press

More->Account.

You can also press **Menu->Status->More->Account.**

The LCD screen displays the connected PSTN account status:

- Default Account
- Registered
- Unregistered
- Disabled

Yealink

Expansion PSTN Box CPN10 Quick Start Guide

PSTN box CPN10 is used to connect CP860 conference phones to the PSTN (Public Switched Telephone Network). It is a cost-effective solution for PSTN office. Up to 2 cascaded PSTN Boxes can be installed to an IP conference phone, which allows you to experience the local three-way conference conveniently in excellent speech quality with PSTN. You can also record the calls with a USB flash drive when using the PSTN box.

Packaging Contents



PSTN Box
CPN10



3m PSTN
Cable




Double-side
Tape



Quick Start Guide


Hardware Component Instructions

The following figure shows the primary hardware components of CPN10:




Installing the Expansion PSTN Box

Installing a PSTN box , as shown below:



Installing two PSTN boxes for three-way local conference, as shown below:







You can fix the two cascaded PSTN boxes by the double-side tape.

Configuring the PSTN Account



When one PSTN box is connected successfully, the LCD screen prompts "Connect PSTN1 Go to Setting?". When the second PSTN box CPN10 is connected successfully, the LCD screen prompts "Connect PSTN2 Go to Setting?".

Configuring the PSTN account:

1. Press the **OK** soft key to enter the Account setting screen.
2. (Optional.) Press  or  to select the desired PSTN account.
3. Press the **Enter** soft key.
4. Press  or  soft key to select **Enabled** or **Disabled** from the **Active Line** field.
5. (Optional.) Enter the string that will appear on the LCD screen in the **Label** field.
6. Press the **Save** soft key to accept the change.

PSTN account is also configurable at the path: **Menu** -> **Settings**-> **Advanced Settings** (default password: admin)-> **Account**.

Setting the default account:

1. Press **Menu**-> **Settings**-> **Advanced Settings** (default password: admin)-> **Account**.
2. Press  or  to select the desired PSTN account.
3. Press the **Default** soft key.